

# Pedestrian Guide for HIT-NOT® Systems



- **PAD is to be worn on the chest in a HIT-NOT® Vest or Pouch where the light is visible and the sounder is audible.**
- A daily check to verify the PAD is functioning visually and audibly is advised. Devices are available for daily test.
- PAD has an LED visual indicator AND an 85 dBa minimum sounder to alert the user.
- Warning Zone (series of 3 beeps)  
Danger Zone (continuous signal)
- LED blinks every 15 seconds to alert the user the PAD is in working order.
- If the battery voltage drops to approximately 3.5 Vdc, the PAD will signal a low battery condition with two rapid beeps.
- NOTE: THE PAD WILL CEASE TO GIVE ZONE WARNINGS WHILE SENDING THE LOW BATTERY ALERT. CHARGE PAD IMMEDIATELY!

## Charging

- PAD is to be fully charged before use.
- **PAD is to be charged daily and connected to the charger over the weekend and holidays.**
- Only use an approved 3.7 Li-ion/Polymer Battery Charger. Chargers are designed to operate with input voltage from 100 to 240 Vac, 50/60 Hz.
- **The PAD is powered by a Lithium Ion Protected Battery. Only use an approved, protected Lithium Ion Battery. Contact HIT-NOT® for the approved replacement battery list.**
- PAD will sound alarm for 2 seconds when disconnected from the charger.

