

FACILITY MARKER MODULE – TRACKING Installation Guide

STEPS FOR FMM-T INSTALLATION

STEP 1: Placement of Unit (Fig. 1-2)

First remove the 4 screws on the top of the FMM-T to access the battery, then remove the battery tabs to turn on the FMM-T. The FMM-T can be mounted to walls, posts, etc. or placed on a flat surface. Keep at least 5' (2m) from electrical power lines, machines, or fluorescent lights. **Install arrows parallel to vehicle travel for best range. Avoid placing near Silent zones, they will cause the battery life on the FMM-T to deplete faster.**



Fig. 1

MFG FIELD SIZE (Danger with PAD)	FMM-T DETECTION (Parallel Axis)	FMM-T DETECTION (Adjacent Axis)
30' (9.1m)	28 (8.5m)	14 (4.2m)
28' (8.5m)	24 (7.3m)	11 (3.3m)
26' (8m)	23 (7m)	11 (3.3m)
24' (7.3m)	21 (6.4m)	11 (3.3m)
22' (6.7m)	19 (5.7m)	9 (2.7m)
20' (6m)	17 (5.1m)	9 (2.7m)
18' (5.4m)	16 (4.8m)	9 (2.7m)
16 (4.8m)	14 (4.2m)	5 (1.5m)

Fig. 2

STEP 2: Powering Unit (Fig. 3)

Only use with provided batteries. The FMM-T will send the user a notification by email when the device battery is getting low to change the batteries remove the 4 screws and replace it with the HIT-NOT® batteries only. **Estimated battery life of 5-10 years.**



Fig. 3

STEP 3: Accessing the Dashboard (Fig. 4)

Log in to your account. Enter the tenant, username, and password. Locate the menu button in the top left side of the landing page. Then proceed to select the dashboard. Then select Proximity Heatmaps landing page.

User LoginReset password / Guest

✔ Successfully logged out.

Tenant:

Company tenant code

Username:

Username or e-mail

Password:

Password:

Login

Fig. 4

STEPS FOR FMM-T INSTALLATION

STEP 4: Accessing Dashboard (Fig. 5)

After Logging into the dashboard, then click on the menu icon then click the proximity heatmap.

STEP 5: Filtering the Dashboard (Fig. 6-7)

After accessing the dashboard, the user may filter the proximity events through the following. (Fig. 7)

STEP 6: Travel Time Summary (Fig. 8-9)

To access zone reports, begin by opening the Menu, select Zone Reports and then choose Travel Summary. From here you will be able to see the interactions of the MGF and the FMM-T zones as well as the travel time and dwell time of each of the vehicles. The data can be filtered through the following. (Fig. 9)




Fig. 6

Filters	
== (equal to)	Filter allows for an exact date and time
!= (not equal to)	On
< (less than)	Filter dates before the chosen date
<= (less than or equal to)	Filter dates before and including the chosen date
> (greater than)	Filter dates after the chosen date
>= (greater than or equal to)	Filter dates before and including the chosen date
between	Filter between two dates and times

Fig. 7

Filters	
== (equal to)	Filter allows for an exact device serial number
!= (not equal to)	On
< (less than)	Filter device serial number less than the given serial number
<= (less than or equal to)	Filter device serial number less than the given serial number including the device serial number
> (greater than)	Filter device serial number greater than the given serial number
>= (greater than or equal to)	Filter device serial number greater than the given serial number including the device serial number
between	Filter between two device serial number

Fig. 8

STEPS FOR FMM-T INSTALLATION




Fig. 5

Proximity Reports												
Main Menu												
<ul style="list-style-type: none"> Home Dashboards Zone Reports <ul style="list-style-type: none"> All Interactions Proximity Events MAC Events FMM Events Marker Summary Prox Loc Summary Travel History Travel Summary Relay Prox Events Special Reports Access Control Reference Types Sites Hit-Not Devices 												
Route Events												
<div> <div> <div></div> <div></div> <div></div> <div></div> <div></div> </div> <div>Item 1 to 20 of 200</div> <div> <div></div> <div></div> <div></div> <div></div> </div> </div>												
<input type="checkbox"/>	Device Type	Device	Equipment Class	Equipment	Start Marker Type	Start Marker	Start Location	End Marker Type	End Marker	End Location	Start Time	End Time
<input type="checkbox"/>	MFG	602445			FMM T	1095					2024-11-27 16:22:29	
<input type="checkbox"/>	MFG	602445			FMM T	1097					2024-11-27 10:42:57	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	1047					2024-11-11 14:09:07	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	1047					2024-11-11 14:08:47	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	1003					2024-11-11 14:01:32	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	1003					2024-11-11 13:50:39	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	1003					2024-11-11 13:50:30	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	1003					2024-11-11 13:49:43	
<input type="checkbox"/>	MFG	601432			FMM T	1003					2024-11-11 13:47:36	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	104					2024-08-27 14:31:00	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	104					2024-08-27 14:30:50	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	1093					2024-07-16 18:37:06	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	25					2024-07-16 18:36:40	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM T	104					2024-07-16 18:36:28	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM EA	-2					2024-03-05 19:21:47	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM EA	-2					2024-03-05 19:18:00	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM EA	-2					2024-03-05 19:16:40	
<input type="checkbox"/>	MFG	600856	equipment	Black	FMM EA	-2					2024-03-05 19:15:22	
<input type="checkbox"/>	MFG	600905	equipment	Whiry Jig	FMM T	104					2024-09-03 08:33:43	
<input type="checkbox"/>	MFG	600905	equipment	Whiry Jig	FMM T	20					2024-08-29 15:07:37	

Fig. 9

HIT-NOT® WARRANTY TERMS AND CONDITIONS

HIT-NOT® WARRANTY TERMS AND CONDITIONS

IMPORTANT-READ CAREFULLY: BY AND INSTALLING AND USING THE HIT-NOT® SYSTEM, YOU ACKNOWLEDGE AND AGREE TO BE CONTRACTUALLY BOUND BY THESE WARRANTY TERMS AND CONDITIONS. IF ANY OF THE TERMS OF USE ARE NOT ACCEPTABLE TO YOU, DO NOT INSTALL OR USE THE HIT-NOT® SYSTEM.

THE HIT-NOT® SYSTEM IS SIMPLY A TOOL TO BE USED TO ASSIST YOU IN SAFELY OPERATING HEAVY EQUIPMENT. THE HIT-NOT® SYSTEM IS NOT INTENDED AS A SUBSTITUTE FOR, NOR DOES IT REPLACE, SAFE PRACTICES IN OPERATING HEAVY EQUIPMENT. YOUR USE OF THE HIT-NOT® SYSTEM IS SOLELY AT YOUR OWN INDEPENDENT DISCRETION AND RISK. THE HIT-NOT® SYSTEM IS NOT GUARANTEED TO PREVENT ACCIDENTS.

ACCEPTANCE AND DEFINITIONS.

(A) Acceptance of Terms. These Warranty Terms and Conditions (these "Terms") are a legal agreement between You, as a purchaser and end user of the System and Frederick Mobile Instrumentation, LLC. By installing the System or using the System in any way, You are (1) agreeing to be bound by these Terms. IF YOU DO NOT AGREE WITH ALL THESE TERMS, DO NOT USE OR INSTALL THE SYSTEM. YOU MUST RETURN THE SYSTEM TO THE DEALER FROM WHICH YOU PURCHASED THE SYSTEM, IN ACCORDANCE WITH THE DEALER'S POLICIES. This Agreement constitutes the entire and only agreement between FMI and You and supersedes all prior or contemporaneous agreements, representations, warranties and understandings with respect to the System, and the subject matter of this Agreement.

(B) Definitions. In this Agreement, "You" and "Your" refer to You as the user of the System. "FMI" "we," "us" and "our" refer to Frederick Mobile Instrumentation, LLC and our successors, partners, affiliates, subsidiaries and assigns. "System" refers to the Hit-Not® System purchased by You. "Terms" refers, collectively, to these Warranty Terms and Conditions.

LIMITED WARRANTIES; DISCLAIMER.

(A) Limited Warranty. FMI hereby warrants against: (1) defects in the System, either in workmanship or material, and (2) the failure of the System to conform to FMI's written specifications, for a period of one (1) year after date of delivery to You, in each case; provided that such System has been under proper and normal use at all times during such period. All warranty claims under these Terms must be submitted through the Dealer from which you purchased the System. FMI's liability is restricted to the replacement or repair of the defective or nonconforming parts alone and does not include any installation, labor, or expense involved, or other contingent liability. Liability for any components manufactured by third parties but incorporated into FMI Products to be furnished by FMI, shall be limited to the guarantee or liability to FMI of the manufacturer or supplier of such components. FMI is not liable for damages resulting from the use or misuse of the FMI Products.

(B) Disclaimers. EXCEPT AS EXPRESSLY SET FORTH ABOVE: (1) NO ADVICE OR INFORMATION, WHETHER ORAL OR WRITTEN, PROVIDED BY OR THROUGH FMI, ANY DEALER OR DISTRIBUTOR, OR ANY THIRD PARTY SHALL IMPLY THE CREATION OF ANY REPRESENTATION OR WARRANTY OF ANY KIND WHATSOEVER BY FMI; (2) THE SYSTEM IS PROVIDED "AS IS" AND WITHOUT ANY WARRANTY OF ANY KIND, EITHER EXPRESS, STATUTORY OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE; (3) FMI DOES NOT REPRESENT OR WARRANT THAT THE SYSTEM WILL BE FUNCTIONAL OR DEFECT-FREE, OR THAT DEFECTS WILL BE CORRECTED; AND (4) FMI HEREBY DISCLAIMS ANY AND ALL LIABILITY OR RESPONSIBILITY FOR THE IMPROPER USE OF THE SYSTEM OR FOR THE INCORRECT OR IMPROPER INSTALLATION OF THE SYSTEM. SOME STATES OR OTHER JURISDICTIONS DO NOT ALLOW THE EXCLUSION OF IMPLIED WARRANTIES, SO THE ABOVE EXCLUSIONS MAY NOT APPLY TO YOU. UNDER NO CIRCUMSTANCES WILL FMI BE LIABLE FOR ANY LOSS OR DAMAGE CAUSED BY YOUR USE OF THE SYSTEM. USE OF THE SYSTEM IS AT YOUR SOLE RISK.

INDEMNIFICATION; RELEASE; LIMITATION OF LIABILITY.

(A) Indemnification. You agree to indemnify and hold FMI, any and all parent, subsidiary, and affiliate organizations, and their respective officers, directors, agents, shareholders, members, managers, advisors, consultants, employees, successors and assigns (collectively, the "Protected Parties") harmless from and against all losses, costs, liabilities, expenses (including reasonable attorneys' fees and expenses), claims, demands, and damages, actual and consequential, of every kind and nature, known and unknown, suspected and unsuspected, disclosed and undisclosed (collectively, "Losses"), that are in any way due to or arising out of Your use of the System, unless caused by the gross negligence or willful misconduct of FMI. FMI reserves the right, at Your expense, to assume the exclusive defense and control of any matter for which You are required to indemnify any of the Protected Parties, and You agree to cooperate with FMI's defense of such claims. FMI will use reasonable efforts to notify You of any such claim, action, or proceeding which is subject to this indemnification upon FMI becoming aware of it.

(B) Limitation of Liabilities. IN NO EVENT SHALL FMI, ITS LICENSORS, SUPPLIERS, CONTENT PROVIDERS OR THEIR RESPECTIVE PARENTS, SUBSIDIARIES, AFFILIATES, OFFICERS, DIRECTORS, SHAREHOLDERS, ADVISORS, CONSULTANTS, EMPLOYEES, SUCCESSORS OR ASSIGNS, BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL, PUNITIVE OR EXEMPLARY DAMAGES (INCLUDING BUT NOT LIMITED TO LOSS OF BUSINESS, PROFITS, USE, REVENUE OR OTHER ECONOMIC ADVANTAGE), ARISING OUT OF OR IN CONNECTION WITH THE SYSTEM OR THESE TERMS BASED ON ANY THEORY, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE LIMITATION OF DAMAGES SET FORTH ABOVE IS A FUNDAMENTAL ELEMENT OF THE BASIS OF THE BARGAIN BETWEEN US AND YOU. THE SYSTEM WOULD NOT BE PROVIDED FOR SALE TO YOU WITHOUT SUCH LIMITATIONS. IN NO EVENT WILL OUR LIABILITY, OR THE LIABILITY OF OUR LICENSORS, AND OUR RESPECTIVE PARENTS, AFFILIATES, SUBSIDIARIES, OFFICERS, DIRECTORS, SHAREHOLDERS, EMPLOYEES, ADVISORS, CONSULTANTS, SUCCESSORS OR ASSIGNS, TO YOU OR ANY THIRD PARTIES IN ANY CIRCUMSTANCE EXCEED ONE HUNDRED DOLLARS (US \$100.00). SOME STATES OR OTHER JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS AND EXCLUSIONS MAY NOT APPLY TO YOU.

CHOICE OF LAW; DISPUTE RESOLUTION. The Agreement shall be governed by, and construed in accordance with the laws of the State of Alabama, without regard to its conflicts of law provisions. In the event of any dispute, claim, question or disagreement ("Claim") between You and FMI arising from or relating to Your use of the System, You and FMI will attempt, in good faith, to resolve any Claim within thirty (30) days after written notice of the Claim. Any Claim not so resolved shall be finally settled by binding arbitration administered by the American Arbitration Association under its Commercial Arbitration Rules, using the Expedited Procedures. Judgment on the award rendered by the arbitrator(s) may be entered in any court of competent jurisdiction. The arbitrator shall be an individual generally skilled in the legal and business aspects of the subject matter of this Agreement. The arbitrator shall have no authority to impose penalties or award punitive damages. The arbitration shall take place in Madison County, Alabama, and the arbitrator shall apply the law of the State of Alabama and applicable rules of evidence. If all parties and the arbitrator agree, arbitration may take place by telephone or by written communication. Unless the arbitrator otherwise directs, the parties, their representatives, other participants, and the arbitrator shall hold the existence, content, and result of the arbitration in confidence. No action, regardless of form, related to the obligations of the parties under this Agreement may be brought by either party against the other more than one (1) year after the cause of action has accrued. In any proceeding to enforce this Agreement, the prevailing party will have the right, in addition to its other rights hereunder, to recover its reasonable litigation costs and reasonable attorneys' fees.

Nothing in this Section shall preclude any party from seeking equitable relief from a court of competent jurisdiction or exercising any self-help remedies, whether before, during or after the pendency of any arbitration proceeding. The parties agree that taking any such action does not waive any right that either party has to demand arbitration at any time with respect to subsequent or amended disputes claimed or filed against a party after commencement of litigation. BY AGREEING TO THESE TERMS AND CONDITIONS, ALL PARTIES AGREE TO WAIVE ANY RIGHTS TO A JURY OR COURT TRIAL. If any provision of this dispute resolution procedure is held invalid or unenforceable, the remaining provisions shall remain in full force and shall not be affected by the invalidity of any other provision. By tapping "Accept", you again agree and confirm that you have read and understood these Terms of Service and the

[Disclaimer](#) [Accept](#)

V. ENTIRE AGREEMENT; ASSIGNMENT; MISCELLANEOUS. These Terms constitute the complete and exclusive statement of the agreement between You and us. It supersedes any and all prior or contemporaneous agreement, oral or written, and any other communications, representations, warranties and understanding relating to the subject matter hereof. If there is a conflict between an oral or written representation of any FMI employee or agent, or any Dealer or Distributor employee or agent, and these Terms, these Terms will prevail. These Terms will prevail over other rules and policies on the System. Our failure to enforce any provision of these terms shall not be deemed either a waiver of such provision or a waiver of the right to enforce such provision. If any provision of these Terms is held by an arbitrator or court of competent jurisdiction to be contrary to law, then such provision shall be construed, as nearly as possible, to reflect the intentions of the parties and the other provisions shall remain in full force and effect. The provision of these Terms which, by their terms should survive termination or expiration of these Terms, shall survive the termination or expiration hereof. FMI may assign this Agreement to any other entity of its choosing, with or without notice to You. You may not assign these Terms to any other party without the prior written consent of FMI. FMI shall not be deemed to have waived any of its rights or remedies unless such waiver is in writing and signed by FMI. No delay or omission on the part of FMI in exercising any rights or remedies shall operate as a waiver of such rights or remedies or any other rights or remedies on future occasions. The section titles in these Terms are solely used for the convenience of the parties and have no legal or contractual significance.

END OF HIT-NOT® WARRANTY TERMS AND CONDITIONS



www.hitnot.com